

Should a Medical Device Incident ARISE

A Assess & Protect the Patient

R Report to a Supervisor

I Isolate the Equipment

S Speak to Biomedical Engineering
(After Hours Number Available)

E Enter BCPSLS Report
• Provide Biomed Device # in report

Isolate the Equipment

- Leave accessories and disposables (e.g. IV sets, bags, wires, pads) 'as is' on the device.
- Keep packaging materials if available.
- If possible, leave device turned **ON** and plugged into a power supply.
- If possible, keep all devices attached in 'as is' state (e.g. do not disconnect any pump modules from PCU brain).
- Label the device as "PSLS" so staff are aware it was involved in an incident.
- If possible, consult Biomed before cleaning device to ensure 'as is' state.
- All supporting photos and videos of the equipment are helpful.

